1/1 19-June-2018



Dakota 4 Drawer Desk

5375: DA-OS-DE-WH

With Optional Dakota Hutch

5376: DA-OS-HU-WH

Congratulations on the purchase of your Dakota Desk. This desk has been crafted to the highest standards of quality and safety and will give you many years of enjoyment and practical use.

Since this desk is a natural wood product, there will be variations in color and grain, and minor wood grain checking may occur. This is normal and does not compromise the integrity of your dresser. Variation in the character of this piece is integral to its beauty and distinguishes it from lower quality composite materials.

Assembly is guite simple and requires only a flat head or Phillips head screwdriver. The use of a power drill with the clutch set to low and a Phillips head attachment is helpful but not necessary. Assembly will be most easily accomplished if you take the time to carefully sort the hardware and familiarize yourself with the function of each piece.

If you should require assistance with assembly, part replacement or any other matter, contact the toll-free Epoch Design Service Center from anywhere in the Continental United States, Monday through Friday, 9 AM – 5 PM Pacific Standard Time at 1-800-589-7990. You may also email your request or comments to info@epochbydesign.com and a service representative will respond.

Thank you and Enjoy **HUTCH HARDWARE OPTIONAL HUTCH** DAKOTA DESK <mmmmmx</pre> (0 0 8x 20 mm wood screws 2x Connector Brackets Used to secure Used to connect Desk to Hutch Desk to hutch Carefully lower and align the hutch on to the back of the desk. Drawer handles are Ι pre-installed into each II) drawer for shipping. (As shown in Diagram I) To install drawer handles, first unscrew the handle from the inside of the drawer. Place the handle on the outside of the drawer and insert the screw through the pre-drilled hole located on the inside Attach the safety of the drawer. Tighten using a flat head or Phillips head connector brackets using screwdriver. (As shown in Diagram II). 8 four 20mm wood screws for each connector. WARNING

Furniture tipping over can create a significant hazard in the home, particularly to young children, although adults can be injured as well. It is necessary that casegoods over 30" in height be secured with some form of anti-tip over device. This desk and hutch come with anti-tip over straps that reduce the risk of tipping. These can be easily installed in minutes and must be used, especially where children are concerned and where earthquakes may pose a hazard. Please note: These straps will reduce the risk of dresser tip-over, they will not eliminate that risk.