

Model 5350

Congratulations on the purchase of your Gabriel Hardwood Dresser. This chest of drawers has been crafted to highest standards of quality and safety and will give you many years of enjoyment and practical use.

This dresser is a natural wood product and has been finished with a distressed patina. There will be variations in color and grain, and minor wood grain checking may occur. This is normal and does not compromise the integrity of your dresser. Variation in the character of this piece is integral to it's beauty and distinguishes it from lower quality materials.



On this insert you will find a list of the hardware and parts necessary for assembly, as well as detailed instructions. Assembly is quite simple and requires only a flat head screwdriver or a phillips head screwdriver.

If you should require assistance with assembly, part replacement or any other matter, contact the toll-free Epoch Design Service Center from anywhere in the Continental United States, Monday through Friday, 9AM - 5PM Pacific Standard Time at 1-800-589-7990.

Thank you and Enjoy.


Drawer handles are pre-installed into each drawer for shipping (As Shown in Diagram I)

To install drawer handles for use you must first unscrew the handle

To install drawer handles for use you must first unscrew the handle from the inside of the drawer.

Place the handle on the outside of drawer and insert screw through the pre-drilled hole located on the inside of the drawer. Tighten using Flathead or Phillips head screw driver.


(As Shown in Diagram II)




If you find you need to remove a drawer, pull drawer all the way out, push and hold track tabs in their proper positions.

(As Shown in Diagram III)
Pull drawer out the rest of the way.

NOTE: Each drawer is made only for its original location so make sure if you remove more than one they go back in proper order.








Epoch Design, LLC





Remove the knob from the inside of the drawer by holding the screw in place and turning the knob counter clockwise.


To attach the knob, insert the machine screw inside the drawer and hold while turning clockwise until tight.



Have a question?? Need a part ASAP?? Please call 1-800-589-7990 (9am to 5pm PST)


Epoch Design, LLC

DRAWER KNOB INSTALLATION



Remove the knob from the inside of the drawer by holding the screw in place and turning the knob counter clockwise.

To attach the knob, insert the machine screw inside the drawer and hold while turning clockwise until tight.



Have a question?? Need a part ASAP?? Please call 1-800-589-7990 (9am to 5pm PST)